



Parametrar att andra:

P101: 1 (Analogstyrning)

P102: 1 (Start / stopp via I/O)

P301: 5 (Max spanning analogutgangen kommer upp i)

P312: 50, 300, 400 (Hz ut vid max analogspanning,
400hz for 24000rpm spindel, 300hz for 18000rpm
ca 50-100hz for vanlig 3-fasmotor)

JB CNC & Linear Components

JB	Rev 1.0	
	2020-07-06	